


Mode Control Switch (R/H)



Wire colour key

| | |
|---|--------|
| B | Black |
| w | White |
| N | Brown |
| Y | Yellow |
| U | Blue |
| G | Green |
| K | Pink |
| R | Red |
| S | Slate |